

Manual

Bluetooth Earmuff



Image is an example only

Product number: EP18121 and EP18122

PACKAGE CONTENT

Before attempting to use the device read the instructions carefully and make sure the following objects are included in the packaging:

Pieces	Accessory	Note
1	Earmuff	integrated battery
1	Micro USB cable	-
1	Manual	-

TECHNISCHE DATEN		
Data connection	Bluetooth 4.1+ EDR	
Frequency range	2.402 GHz - 2.480 GHz	
Frequency	UHF	
Max. transmission	2.92 mW	
Transmission range	10 m	
Run time	up to 8 h	
Stand-by time	up to 80 h	
Charging time	ca. 2,5 h	

INBETRIEBNAHME

Step 1: To switch on press the button in the middle (Play/Pause) until a blue LED starts blinking and you hear "Power on". To switch off, press the same button (Play/Pause) until the LED stops blinking and you hear "Power off".

Step 2: To connect with a bluetooth device: Press the Play/Pause button until the LED starts blinking red and blue alternately and you hear "Pairing". Now the earmuff can be found by the bluetooth device and is ready for pairing.

Step 3: Switch on bluetooth at your device and look for "MTO Bluetooth earmuff" and connect. At first pairing the LED blinks blue and you will hear "Paired". Once successfully paired the earmuff will connect automatically to your device.

Step 4: To play music use the button in the middle (Play/Pause), the one above

(forward) and below (backward). To adjust volume long press the above button (volume up) or the below button (volume down).

Step 5: In case of an incoming call the number will be pronounced. To answer or hang up press the Play/Pause button. To redial the last number press the Play/Pause button shortly twice.

CHARGING THE INTEGRATED BATTERY

When the battery is low (about 20% left) the speaker alerts acoustically. At 15% it switches off Bluetooth automatically. In this case, charge the speaker as soon as possible. Use the included cable to charge. The red indicator light will stay on while charging. Once it has finished charging, the indicator light will go out.

SAFETY NOTES

For your own safety and for long enjoyment of our product, please follow the following safety instructions:

- Please use device as described in the manual.
- Please keep the device dry and use in dry environment only. Do not touch with wet hands. **Must not be washed!**
- Keep away from damp, high temperature, dusty, erosive and oxidative environment.
- Do not open cover and do not touch inner parts.

DISPOSAL

This device contains materials that must not be disposed of as household waste. Please check local laws concerning the applicable disposal regulations. Protect the environment by participating in recycling programs.

DECLARATION OF CONFORMITY

LEICKE GmbH herewith declares that the devices EP18121 and EP18122 comply with the RED 2014/53/EU and ROHS 2011/65/EC regulations. The declaration of conformity can be found at: www.leicke.com/de/products/EP18121 www.leicke.com/de/products/EP18122

CONTACT

Please contact us in case of questions!



