



## Manual

### Bluetooth-TWS-Headset



Image is an example only  
Product number: **EP18143**

---

## PACKAGE CONTENT

Before attempting to use the device read the instructions carefully and make sure the following objects are included in the packaging:

Pieces	Accessory	Note
1	Wireless headset	integrated battery
1	Micro USB cable	-
1	Manual	-
1	Charging station	

## TECHNICAL DETAILS

Data connection	Bluetooth 4.1
Frequency range	2.402 GHz - 2.480 GHz
Frequency	UHF
Max. transmission	2.92 mW
Transmission range	10 m
Run time	up to 4 h
Stand-by time	up to 100 h
Charging time	ca. 2 h

## FUNCTION

### Switching on:

Press the multifunction button for 3 seconds. "Power on" alert.

### Switching off:

Press one of the multifunction buttons for 5 seconds. "Power off" alert.

### Pairing:

Turn on both sets of earphone, wait for 2 seconds (starting with the headset switched off). "Pairing" alert. The earphone's LED will flash red and blue. After this step, the left earphone and right earphone will be paired automatically. If no, please follow the below step A.

A) Turn on both sets of earphone (press and hold the multifunction button for 2 seconds, Red&Blue LED light on, then long press one earphone set's multi-function button 3 seconds, the earphones will pair with each other and you will hear "connected" Then look

---

for “LEICKE EP18143” in the phone’s Bluetooth menu and select it.

**Multi-point pairing with multiple devices:**

Pair with device 1, then switch off Bluetooth of said device. Pair with device 2. Switch on Bluetooth on device 1 again.

**Incoming call:**

Press the multifunction button to answer/hang up. Long press the multifunction button to decline the call.

**Call last number:**

Press the multifunction button twice.

**Music control:**

Press the multifunction button to play or pause music.

**Low-battery warning:**


“Low-battery” alert and blue LED, then the headset will go into stand-by.

**Headset charging:**


Insert it into the base. When the battery is fully charged, the LED will flash blue then turn off.

**Charging the base:**


Via the micro USB cable. When the battery is fully charged, the LED will turn blue.



Charging LED  
for the base



Micro USB  
charging port



Multifunction button

LED

Microphone

---

## SAFETY NOTES

For your own safety and for long enjoyment of our product, please follow the following safety instructions:

Please use device as described in the manual.

Please keep the device dry and use in dry environment only. Do not touch with wet hands.

Keep away from damp, high temperature, dusty, erosive and oxidative environment.

Do not open cover and do not touch inner parts.

## DISPOSAL

This device contains materials that must not be disposed of as household waste. Please check local laws concerning the applicable disposal regulations. Protect the environment by participating in recycling programs.



## DECLARATION OF CONFORMITY

LEICKE GmbH herewith declares that the devices EP18143 comply with the RED 2014/53/EU and ROHS 2011/65/EC regulations. The declaration of conformity can be found at:  
[www.leicke.com/de/products/EP18143](http://www.leicke.com/de/products/EP18143)



## CONTACT

**Please contact us in case of questions!**

### PRODUCTION & DISTRIBUTION

**LEICKE GmbH**  
Dohnanystr. 28  
04103 Leipzig  
GERMANY

**Web: [www.leicke.com](http://www.leicke.com)**  
**Mail: [info@leicke.com](mailto:info@leicke.com)**

