

User's Manual

Aluminium Bluetooth 3.0 Keyboard for Galaxy Note N8000 10.1



Product number: SI54143

Thank you for purchasing the Galaxy Note N8000 Protection Case with integrated Bluetooth keyboard from Sharon.

We hold several brands to produce and distribute our products: **LEICKE** (power adapters, batteries), **KanaaN** (adapters/converters, charging cables etc.), **Sharon** (iPad cases with keyboard, fans etc.), **Hebron** (protective cases, docking stations, screen protectors etc.), **Manna** (notebook cases).

We continuously work on the development of our products, our customer support and innovations. Our products have a long service life, are eco-friendly and high performing. Furthermore, every day we do our very best to satisfy you as our customer. That is why you, no matter if private or business customer, are in the focus of our company's efforts. We take your reviews and proposals seriously and evaluate them continuously. That way, we get to know you and your demands on our products and services better and thus allow for positive enhancements.

To discover more about LEICKE products, or if you have any questions about this product, visit our website
www.leicke.com.

PACKAGE CONTENTS

Before attempting to use this device, please check the packaging and make sure the following items are contained in the package:

Number of Pieces	Name	Note
1	Keyboard cover	Aluminium case, Bluetooth 3.0, integrated battery
1	USB charging cable	-
1	User's Manual	Language depends on model

PRODUCT INFORMATION

- Lightweight Bluetooth 3.0 keyboard with ultra-thin aluminium case.
- Compatible with Samsung Galaxy Note 10.1 N8000
- Built-in rechargeable lithium battery
- Special function keys for one touch access to a variety of applications
- Energy-saving sleep mode
- Easy to charge thanks to micro USB port
- Protects the display when folded

TECHNICAL DETAILS

Interface	Bluetooth 3.0
Operating distance	ca. 10 m
Frequency modulation	FHSS
Operating voltage	3.3-5.0 V
Working current	< 5,0 mA
Sleeping current	< 200 μ A
Charging current	\geq 100 mA
Standby time	70 days
Charging time	2-3 h
Lithium battery capacity	180 mA
Uninterrupted working time	50 h
Key strength	80 g \pm 10 g
Humidity during operating	20% to 50% RH
Operating Temperature	-20°C to 55°C

CONTROL ELEMENTS



1: Keyboard

4: ON/OFF switch

2: Connect button

5: Holder for tablet

3: Status LED (Charging / Bluetooth)

6: Small rack to hold the tablet

ESTABLISHING THE BLUETOOTH CONNECTION

Step 1: Turn the keyboard on by pressing on/off switch. The Bluetooth LED flashes for a second. If that is not the case, please charge the keyboard.

Step 2: Press the connect button. The Bluetooth control LED shows by flashing that connection is possible.

Step 3: Turn on the Galaxy Note. Tap on the device's settings icon.

Step 4: In the settings menu, select [Bluetooth] settings. If Bluetooth is switched off, please activate it. Available devices will be shown now.

Step 5: Your Galaxy Note will now display the available devices. The keyboard will be shown with a keyboard symbol and a device code or the description "bluetooth

keyboard". Tap on the keyboard symbol to connect the keyboard with your tablet.

Step 6: Your device will now display a code. Enter the password code via the Bluetooth keyboard as displayed on screen and tap on the Return key.

Step 7: The keyboard is now successfully connected and will be shown in the list of the recognized devices. The Bluetooth LED stops flashing.

Note: The keyboard can be used with all devices which support Android 2.0 or higher. For other Bluetooth-enabled devices, please verify the Bluetooth standard & compatibility before attempting to connect to the keyboard.

Once successfully connected, the keyboard saves all connection data until connected to another device.

CHARGING THE INTEGRATED BATTERY

When the battery power is low, the [power] indicator light will start blinking. It is time to recharge the keyboard.

Step 1: Connect the USB power cable to the keyboard charging micro USB interface.

Step 2: Connect the charging cable with the USB-A plug to a power adapter or computer's USB interface.

Step 3: The [charge] indicator light will stay on when the keyboard is charging.

ENERGY SAVING SLEEP MODE

The keyboard will change into sleep mode when it is inactive for 15 minutes and the keyboard [power] indicator light will go off. To activate from sleep mode, just press any key and wait 3seconds. The keyboard will come back on.

SAFETY NOTES

- Please avoid the following situations:
- Keep away from sharp objects, oil, chemicals or any other organic liquids.
- Do not place heavy objects on top of the keyboard.
- Avoid contact to fire, heat or direct sunlight.
- Do not microwave.

SPECIAL KEYS

There are special keys in the first row of the keyboard with special functions, which can be used for media, contrast, home screen or programmes depending on the operating system. You may also insert special letters in combination with the FN key.

CLEANING

Clean the keyboard with a moist cloth. Please avoid using cleaners or disinfectants on alcohol basis. These may harm the surface.

TROUBLE SHOOTING

Please charge the keyboard before the first use, as the integrated battery may be discharged. Please check the proper connection of the charging cable with every charging. If you experience other problems, please check if they may be solved with the following table.

Problem	Possible Cause/Possible Solution
Unable to connect	<ol style="list-style-type: none">1. Make sure the keyboard is switched on and charged.2. Make sure the keyboard is within the operating distance.3. Make sure Bluetooth setting is on.4. Make sure wireless keyboard has been paired with the Galaxy Note.
Layout of the keyboard does not match	Make sure the language settings are correct. The settings of the keyboard's language can be found under "Language and

Problem	Possible Cause/Possible Solution
	Input". Different layouts maybe supported in a single country profile. The correct layout can be set under "keyboard and input modes".
Unable to charge keyboard	<ol style="list-style-type: none"> 1. Make sure the USB power cable is connected properly to the keyboard and the power source. 2. Make sure the wall charger is plug into the power outlet. 3. Make sure, you have the right output voltage.

If the problems cannot be solved, please don't hesitate to contact us.

Galaxy Note is a registered trademark of Samsung.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC-Caution: Any changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate this equipment.

IMPORTANT NOTE:

Radiation Exposure Statement:

1. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users should follow the specific instructions in the user's manual to comply with the FCC rules.
2. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

DISPOSAL



This device contains materials that must not be disposed of as household waste. Please check local laws concerning the applicable disposal regulations. Protect the environment by participating in recycling programs!

CONTACT

If you have any questions, please feel free to contact us.

PRODUCTION, WHOLESALE & DISTRIBUTION

LEICKE GmbH

Dohnanyistr. 28

04103 Leipzig

Germany

Web: www.leicke.com

Mail: info@leicke.com